

Pet Collar Transferring Instructions

Supplies Needed

- Spray Adhesive
- Pet Collar

Step 1: Adjust Heat Press

Heat Press Temperature: **400° F** Dwell Time:
45-50 seconds Pressure: **Firm**

Note: These instructions, including transfer times and temperatures, are based on the inks, paper, equipment and products we use. Other inks, papers, etc. may require adjustments in your time/temp settings.

Step 2: Design Your Transfer

Design your transfer so that it is larger (10.25" x .875") than the Pet Collar or print using registration marks to line-up the image.

Step 3: Prepare the Transfer

- 1 Lightly spray the transfer with spray adhesive.
- 2 Place the transfer face-down on the white sublimatable fabric swatch (Figure 1).



Figure 1



Figure 2

3. Place the Pet Collar and transfer on the heat press, face-up at an angle so that the ends of the collar extend over adjacent sides of the press (Figure 2).
4. Using **Firm** pressure, press at **400° F** for **45-50 seconds**.
5. Remove collar from press and peel transfer. **Customer Support: 877.795.1500**. You may also write to us at support@laserreproductions.com.